



Flexi-Dip Multi-Function Sampling System

For Restricted & Closed Tank Applications

The Flexi-Dip Multi-Function Sampling Tape for Restricted & Closed Tank Applications is available in both 3/4 liter capacity and 1/2 liter capacity.

Each Sampling System comes complete with the **100' Flexi-Dip sampling tape, appropriate vapor valve storage tube, gauging bag, hard storage case, MMC Collar, Hermetic adapter and the Multi-Function Sampler.**

The Multi-Function Sampler allows the operator to choose the type of sampler needed by selecting one of the various tops and bottoms included in the sampling kit. For example, for running samples, the user would choose the Adjust-A-Neck top. For zone samples, the user would choose the zone bottom.

The Multi-Function sampler may also be used for RVP sampling applications. By using the specially designed spring loaded bottom valve and the RVP trip funnel, the user is able to transfer gasoline without losing vapor pressure during the transfer process.

- For closed & restricted sampling on vessels with inert gas pressure.
- Designed to fit MMC or Hermetic vapor control valves.
- Restricts escape of vapors into the atmosphere.
- Meets API sampling requirements for:
 - Running samples
 - All level samples
 - Spot samples
 - Zone samples
 - RVP samples
- Ideally suites for oil inspectors
- Safer for personnel and environment
- Simple and safe to use



Includes FREE gauging bag!!

Catalog No.	Description
S2326100-1LM-RVP	3/4 Liter Multi-Function RVP Sampler
S2326100-1LM	3/4 Liter Multi-Function Sampler